

Mayo Anti-Slip

Fitting Instructions

mayofarmsystems.co.uk 01704 821717



Step One: Layout

Measure area to be fitted and decide on the best way to fit the mats into the area. Each Anti-Slip mat is 5'8" X 4"


Use a brick-work type pattern where possible:



- 12' X 14' Area Shown
- 7.5 Mats needed
- Leave 20mm between each mat
- Cut around any intrusions into space leaving 20mm also (example pictures at end)

Step Two: Fixing

Each mat is held in place with 3 coach screws & washers. The positioning of the bolts is important to get right as shown below:



1. Using a 10mm masonry bit, drill through the mat into the floor making sure the mats are 20mm apart as in the previous step
2. Put the plugs into the holes in the mats, put washer on the screw and place screw into the plug
3. Gently tap until the plug is in the concrete
4. Drive the coach screw using 17mm socket until the head is counter sunk into the mat (head should not protrude at all from the mat when finished).
5. You will use fewer rather than more bolts to start with to make maintenance in the settling in phase easier

Tip: Rather than measuring every mat, it is easier to mark & drill one & then use that as a template for the rest

A Note on Maintenance

- The mats are not designed for use outdoors (may curl)
- Mayo Anti-Slip mats need to be worn into final position
- This means that they will likely require at least 1 trim and potentially a refit of some fixings, depending on the expansion per site, before this process is complete
- You must ensure that **muck is not allowed to build up underneath** the mats as this can cause curling & will void any warranty
- While a bit more work to maintain vs. rubber, our mats will never harden and become slick and slippery like rubber can so you get **permanent traction** in return for your maintenance efforts!

Some Installed Examples

